



### Special sleeper screws with six-edge head

- ▶ ideal for all kinds of sleepers
- ▶ **no spread pressure**  
thanks to self-cutting thread
- ▶ over 25% less installation time
- ▶ high carrying capacity

**Attention:** The drill hole must be cleaned!  
Then turn down the screws until a residual height of 1-2mm and tighten them to 20Nm.

A	B	C	D	E	F	G	H	I	J	K
6 x 35	6	5	40	13	INOX A4	306212.035		230KV4	50	20 for concrete and steel sleepers
6 x 60	6	5	65	13	INOX A4	306212.060		232KV4	50	20 for wooden sleepers

  

A) $\varnothing$ length (mm)	E) Spanner width	I) Packing unit
B) $\varnothing$ Hole in concrete (mm)	F) Material quality	J) Max. Tightening torque (Nm)
C) $\varnothing$ Hole in wood (mm)	G) KAGO product number	K) Kind of sleeper
D) Drilling depth (mm)	H) Screw	



For steel sleepers please use our self-cutting screws 35mm, INOX A2, product number 306210.100.  $\varnothing$  drilling: 5.5 - 5.7 mm.



For steel sleepers please use our self-cutting screws 40mm, INOX A2, product number 306210.200, without pre-drilling.